

## **PRIMING OF SUBSTRATE**

**Priming of certain steel deck substrates and oil contaminated steel decking is sometimes required for the proper adhesion of K-13. Isoprime is one of the primers used to pre-treat these decks. The primer is typically splatter sprayed on the deck and allowed to dry prior to the K-13 application. Retrotherm will determine if the substrate will need priming based on site conditions and input from the owner, contractor, architect, or steel manufacturer.**

**Glass surfaces always need to be primed with a UV inhibited primer to prevent ultraviolet light from penetrating into the K-13 and causing long term damage.**