

## PRIMING OF SUBSTRATE

Priming of certain steel deck substrates and oil contaminated steel decking is sometimes required for the proper adhesion of K-13. Isoprime is one of the primers used to pre-treat these decks. The primer is typically splatter sprayed on the deck and allowed to dry prior to the K-13 application. Retrotherm will determine if the substrate will need priming based on site conditions and input from the owner, contractor, architect, or steel manufacturer.

Glass surfaces always need to be primed with a UV inhibited primer to prevent ultraviolet light from penetrating into the K-13 and causing long term damage.

